

HUSQVARNA 525iB

Well-balanced, comfortable and efficient professional battery blower. The machine's low noise level allows you to work in the most public of settings. An easy tap on the keypad starts the machine instantly at all times and the cruise control means full focus on blowing leafs and debris away. The blower also has a boost power mode that gives you a little extra power when needed.




Low noise levels

Low noise levels enable longer working hours and the possibility to work in noise sensitive and restricted areas



Boost effect

Maximized blowing speed during limited time through easy accessible boost mode.



Working with harness and eyelet equipped machine gives a comfortable working position.



Low maintenance

No refilling of fuel, less parts to serve and an electronically controlled drive system means less downtime and low operation costs.



FEATURES

- Working with harness and eyelet equipped machine gives a comfortable working position.
- Maximized blowing speed through easy accessible boost mode.
- Low noise levels enable longer working hours.
- Low maintenance
- Superb balance, grip and intuitive keypad gives excellent ergonomics.
- Gear up for nonstop operation

- Cruise controlled blowing speed for optimum handling.
- Low total weight through few components and lightweight motor.
- Best performance in class due to the advanced motor fan design.
- Ergonomic handle with easy access to the controls.
- High torque to weight ratio for increased efficiency and reliability.
- Allows you to quickly switch the same battery between different product applications and keep working.

21 min
Li-lon
36 V
12.8 m³/min
11.6 m³/min
48 m/s
48 m/s
4223 g
2860 g
27 cm
90 cm
2.4 kg
BLDC (brushless)
98 dB(A)
97 dB(A)
82 dB(A)
0.4 m/s ²
0.3 m/s ²
2 h
0.5 m/s ²

ACCESSORIES



HUSQVARNA BATTERY BLI100 967 09 18-01



HUSQVARNA BATTERY BLI200 967 09 19-01



HUSQVARNA BATTERY BLI300 967 07 19-01



HUSQVARNA CHARGER QC80 967 33 56-31



HUSQVARNA CHARGER QC80 967 33 56-41



HUSQVARNA CHARGER QC80 967 33 56-51



HUSQVARNA CHARGER QC80 967 33 56-61



HUSQVARNA BATTERY CHARGER 967 33 56-71



HUSQVARNA CHARGER QC330 967 09 14-01



HUSQVARNA CHARGER QC330 967 09 14-02



HUSQVARNA CHARGER QC330 967 09 14-03



HUSQVARNA CHARGER QC330 967 09 14-04



HUSQVARNA CHARGER QC330 967 09 14-05



HUSQVARNA CHARGER QC330 967 09 14-06

HUSQVARNA CHARGER QC500 967 09 15-01

HUSQVARNA CHARGER QC500 967 09 15-02









HUSQVARNA CHARGER QC80F 967 62 83-01

HUSQVARNA INVERTER VI600F 967 62 85-01

HUSQVARNA INVERTER VI600F 967 62 85-02

HUSQVARNA INVERTER VI600F 967 62 85-03



HUSQVARNA INVERTER VI600F 967 62 85-04



HUSQVARNA BATTERY BAG 585 37 18-01



HUSQVARNA BATTERY BOX S 585 42 87-01



CHAIN SAW HOOK 580 80 03-01



HARNESS BALANCE 35 B 537 27 57-05



HIP PAD 587 83 40-01



NOZZLE 579 79 75-01